

abi Hide Away

RECESSED CEILING SCREENS

abi Hide Away is a new Recessed Ceiling motor screen design, with a motorised case opening closure to completely hide the screen. When the remote is pressed, the closure panel opens & then the screen descends. When finished, the screen retracts & the opening is automatically covered by the closure.

To install the screen, simply cut the hole in the ceiling to suit the screen (template included with each plate), install the ceiling rod supports, and position the screen into the opening and bolt the screen into position. Sliding end panels allow access for installation. Out of sight, out of mind, and for a fraction of the cost of other screen manufacturers. Finished in white powdercoat finish to match a standard ceiling.

The **Hide Away** plate system incorporates a remote control to operate the screen, and the system includes a motorised closure plate, so that the screen opening is automatically closed when the screen is not in use.

SPECIFICATIONS



Models:

The initial standard sizes available are all 4:3 format, although any size and format can be manufactured to order. The bottom (visible) plate is 180mm wide & the width of the case into the ceiling is 130mm.

| Product Code | Format | Diagonal | Overall Size | Viewing Size | Top Border | Case Size |
|--------------|-------------|----------|--------------|--------------|------------|----------------------|
| HA100D | Video (4:3) | 100" | 2030 x 1530 | 1950 x 1463 | 300 | 2370 x 180/130 x 170 |
| HA120D | Video (4:3) | 120" | 2440 x 1830 | 2360 x 1770 | 300 | 2860 x 180/130 x 170 |
| HA150D | Video (4:3) | 150" | 3050 x 2290 | 2970 x 2228 | 300 | 3390 x 180/130 x 170 |
| HA180D | Video (4:3) | 180" | 3660 x 2740 | 3580 x 2685 | 300 | 4000 x 180/130 x 170 |
| HA200D | Video (4:3) | 200" | 4065 x 3050 | 3945 x 2959 | 300 | 4485 x 180/130 x 170 |

Installation:

The Hide Away ceiling plate has sliding end panels to access the ceiling space for final installation. Simply cut a hole in the ceiling to suit the plate being used (as per instruction manual) and install threaded rod into the structure above the ceiling (positioning as per instruction manual). Slide the screen mount bracket over the threaded rod (into the ceiling cavity) until the screen ceiling plate is flush against the ceiling. Insert the 2 nuts and tighten. Slide the end panels that enable access to the fixing nuts and the installation is complete. A power plug must be inserted into a power socket in the ceiling cavity.